PARTS LIST & ASSEMBLY DIAGRAM

1	Feeder Pan	2	Meat Stuffer
3	Bearing	4	Grinding Chamber
5	Coupling Cover	6	Pressure Plate
7	Knife	8	Holder
9	Spiral Propeller	10	Plunger
11A	Gear Box	11B	SS Housing
12	Attachment Hub	13	Hub Shaft
14	Worm Shaft	15	Worm Gear
16	Worm	17	Spacer
18A	Complete Motor	19	Motor Shaft & Rotor
20	Motor Stator	21	Bearing Housing
22	Plate	23	Capacitor
24	Cable Tie	25	N/A
26	Sticker of Control Panel	27	Thumb Screw
28	Centrifugal Governor Plate	29	Centrifugal Governor
30	Control Board	31	Ball Bearing
32	Circuit Braker	33	Ball Bearing
34	Oil Seal	35	Oil Seal
36	C-Type Snap Ring	37	Meat Funnel
38	Pin	39	Key
40	Key	41	Nut
42	Screw	43	Screw
44	Screw	45	Screw
46	Screw	47	Screw
48	Screw	49	Handle
50	Grease Taper	51	Screw Driver
52	Screw	53	Spacer

